


1. Make the blade vertical to be 0°.



2. Loosen the screw on the hand wheel and remove the protractor.



3. Take the protractor Vertical, make the pointer to 0 °



4. Set installed the protractor, fasten the screw, and make the blade to  $45^\circ$ . Check to make sure the pointer between  $45-45.5^\circ$ . Then It will be okay.

