

**Spare Part List For Table Saw**

<b>ITEM NO</b>	<b>PART NAME</b>	<b>PART NO</b>	<b>ART NO</b>	<b>FÖRPACKNING</b>
1-21	Guide tube assambly	TSS 254-1-21	262376007	1 st
22-33	Miter gauge assambly	TSS 254-22-33	262376015	1 st
34	Sliding table	TSS 254-34	(262376023)	1 st
35	Cross-screw M5×10	TSS 254-35	-	
36	Flat washer 5	TSS 254-36	-	
37	Socket head bolt M4×10	TSS 254-37	-	
38	Guide rail A	TSS 254-38	(262376031)	1 st
39	Guide rail B	TSS 254-39	(262376049)	1 st
40	Table insert	TSS 254-40	262376056	1 st
41	Socket head bolt M6×16	TSS 254-41	-	
42	Main table	TSS 254-42	-	
43	Left blade guard	TSS 254-43	262376064	1 st
44	Bolt M6×45	TSS 254-44	-	
45	Riving knife	TSS 254-45	262376072	1 st
46	Right blade guard	TSS 254-46	262376080	1 st
47	Cross-screw ST2.9×10	TSS 254-47	-	
48	Extension rail	TSS 254-48	-	
49	Open ring 12	TSS 254-49	-	
50	Rear extension table	TSS 254-50	(262376098)	1 st
51	Hexagon screw M10	TSS 254-51	-	
52	Hexagon screw M14	TSS 254-52	-	
53	Inner handrail	TSS 254-53	-	
54	Outer handrail	TSS 254-54	-	
55	Cross-screw ST4.2×12	TSS 254-55	-	
56	Closure plate B	TSS 254-56	-	
57	Vice scale seat	TSS 254-57	-	
58	Cross-screw ST4.2×8	TSS 254-58	-	
59	Hex nut M6	TSS 254-59	-	
60	Scale label B	TSS 254-60	262376106	1 st
61	Bolt M6×16	TSS 254-61	-	
62	Closure plate A	TSS 254-62	-	
63	Scale label C	TSS 254-63	262376114	1 st
64	Right extension rail	TSS 254-64	-	
65	Extension table	TSS 254-65	(262376122)	1 st
66	Adjusting ring	TSS 254-66	-	
67	Knob	TSS 254-67	-	
68	Big flat washer 5	TSS 254-68	-	
69	Cross-screw M5×20	TSS 254-69	-	
70	Locking knob	TSS 254-70	-	
71	Scale label A	TSS 254-71	262376130	1 st
72	Adjusting plate	TSS 254-72	-	
73	Adjusting screw	TSS 254-73	-	
74	Socket head bolt M6×12	TSS 254-74	-	
75	Socket head bolt M8×40	TSS 254-75	-	
76	Socket head bolt M6×20	TSS 254-76	-	
77	Support base	TSS 254-77	-	
78	Rail seat A	TSS 254-78	262376148	1 st
79	Motor assembly	TSS 254-79	262376155	1 st

80	Fixed platen	TSS 254-80	-	
81	Spring washer 5	TSS 254-81	-	
82	Lift pillar	TSS 254-82	-	
83	Cover plate	TSS 254-83	-	
84	Screw M6x12	TSS 254-84	-	
85	Machine body	TSS 254-85	-	
86	Holder A	TSS 254-86	-	
87	Vane	TSS 254-87	-	
88	Gap film	TSS 254-88	-	
89	Cross-screw M6x16	TSS 254-89	-	
90	Dust extractor port	TSS 254-90	262376163	1 st
91	Inner flange	TSS 254-91	262376171	1 st
92	Saw blade	TSS 254-92	-	
93	Outer flange	TSS 254-93	262376189	1 st
94	Hex nut M16	TSS 254-94	262376197	1 st
95	Socket head bolt M5x20	TSS 254-95	-	
96	Lower baffle	TSS 254-96	-	
97	Hex nut M5	TSS 254-97	-	
98	Lower blade guard	TSS 254-98	-	
99	Spring washer 4	TSS 254-99	-	
100	Small baffle	TSS 254-100	-	
101	Cross-screw M5x12	TSS 254-101	-	
102	Cross-screw M3x25	TSS 254-102	-	
103	Hex nut M3	TSS 254-103	-	
104	Bracket	TSS 254-104	-	
105	Transparent plate	TSS 254-105	-	
106	Big flat washer 4	TSS 254-106	-	
107	Cross-screw ST3.9x10	TSS 254-107	-	
108	Capacitance	TSS 254-108	262376205	1 st
109	Bobbin	TSS 254-109	-	
110	Cross-screw ST3.9x16	TSS 254-110	-	
111	Anti-bending sheath	TSS 254-111	-	
112	Hook	TSS 254-112	-	
113	Cable	TSS 254-113	-	
114	Holder B	TSS 254-114	-	
115	Socket head bolt M6x16	TSS 254-115	-	
116	Shaft collar 10	TSS 254-116	-	
117	Gear	TSS 254-117	-	
118	Lift adjusting base	TSS 254-118	-	
119	Rail B	TSS 254-119	-	
120	Flat key 4x8	TSS 254-120	-	
121	Pointer	TSS 254-121	-	
122	Lift adjusting rail	TSS 254-122	-	
123	Push sticker	TSS 254-123	-	
124	Knob	TSS 254-124	-	
125	Blade wrench	TSS 254-125	-	
126	Socket head bolt M8x35	TSS 254-126	-	
127	Flat washer 8	TSS 254-127	-	
128	Locking sleeve	TSS 254-128	-	
129	Cabinet	TSS 254-129	-	

130	Socket head bolt M8x30	TSS 254-130	-	
131	Positioning plate	TSS 254-131	-	
132	Side plate	TSS 254-132	(262376213)	1 st
133	Adjusting holder	TSS 254-133	262376221	1 st
134	Cross-screw M5x16	TSS 254-134	-	
135	Lower bottom plate	TSS 254-135	-	
13		TSS 254-13	-	
136	Plate for switch	TSS 254-136	262376239	1 st
137	Switch box assembly	TSS 254-137	262376247	1 st
138	Overload protection	TSS 254-138	262376254	1 st
139	Cover for switch	TSS 254-139	262376262	1 st
140	Retaining coil	TSS 254-140	-	
141	Line card	TSS 254-141	-	
142	Label	TSS 254-142	-	
143	Label	TSS 254-143	-	
144	Nut	TSS 254-144	-	
145	Switch	TSS 254-145	262376270	1 st
146	Cross-screw M5x8	TSS 254-146	-	
147	Cross-screw M4x12	TSS 254-147	-	
148	Main label	TSS 254-148	(262376288)	1 st
149	Washer sleeve	TSS 254-149	262376296	1 st
150	Locking compress spring	TSS 254-150	262376304	1 st
151	Compress rail	TSS 254-151	262376312	1 st
152	Hex nut M5	TSS 254-152	-	
153	Locking handle	TSS 254-153	262376320	1 st
154	Socket head bolt M5x12	TSS 254-154	-	
155-158	Handwheel assembly	TSS 254-155-158	262376338	1 st
159	Cross-screw M5x16	TSS 254-159	-	
160	Cross-screw M5x35	TSS 254-160	-	
161	Front cover	TSS 254-161	-	
162	Inner ring	TSS 254-162	-	
163	Bearing	TSS 254-163	-	
164	Rotor	TSS 254-164	-	
165	Cross-screw ST4.9x70	TSS 254-165	-	
166	Stator	TSS 254-166	-	
167	Bearing	TSS 254-167	-	
168	Shock absorption ring	TSS 254-168	-	
169	Cap	TSS 254-169	-	
170	Carbon brush	TSS 254-170	262376346	1 st
171	Brush holder	TSS 254-171	262376353	1 st
172	Compressed line plate	TSS 254-172	-	
173	Cross-screw M5x8	TSS 254-173	-	
174	Cover plate	TSS 254-174	-	
175	Case	TSS 254-175	-	
176	Bearing	TSS 254-176	-	
177	Shaft collar 16	TSS 254-177	-	
178	Gear	TSS 254-178	-	
179	Output shaft	TSS 254-179	-	
180	Woodruff key 5x6.5x16	TSS 254-180	-	
181	Shaft collar 35	TSS 254-181	-	

182	Bearing 6003-2Z	TSS 254-182	-
183	Gear cover	TSS 254-183	-
184	Cross-screw M5x16	TSS 254-184	-
185	5mm Hex key	TSS 254-185	-
186	6mm Hex key	TSS 254-186	-