

**Spare Parts List For Stand**

ITEM NO	PART NAME	PART NO	ART NO	FÖRPACKNING
1	Socket head bolt M8 x 70	TSS 254-1	-	
2	End cap	TSS 254-2	-	
3	Stand support (C)	TSS 254-3	-	
4	Spacer (A)	TSS 254-4	-	
5	Lock Nut M8	TSS 254-5	-	
6	Socket head bolt M8 x 90	TSS 254-6	-	
7	Socket head bolt M8 x 95	TSS 254-7	-	
8	Rolling sleeve	TSS 254-8	-	
9	Spacer (C)	TSS 254-9	-	
10	Socket head bolt M8 x 80	TSS 254-10	-	
11	Stand frame	TSS 254-11	-	
12	Cross-screw M5 x 35	TSS 254-12	-	
13	Upper handle	TSS 254-13	262376361	1 st
14	Locknut M6	TSS 254-14	-	
15	Support bar	TSS 254-15	-	
16	Socket head bolt M6 x 35	TSS 254-16	-	
17	Lower handle	TSS 254-17	262376379	1 st
18	Nut M5	TSS 254-18	-	
19	Cross-screw ST4.2 x 12	TSS 254-19	-	
20	Stand support (B)	TSS 254-20	-	
21	Paddle (A)	TSS 254-21	-	
22	Paddle (C)	TSS 254-22	-	
23	Big flat washer 8	TSS 254-23	-	
24	Bushing	TSS 254-24	-	
25	Wheel assembly	TSS 254-25	262376387	1 st
26	Big flat washer 10	TSS 254-26	-	
27	Flat washer 8	TSS 254-27	-	
28	Button spring	TSS 254-28	-	
29	Spacer bush	TSS 254-29	-	
30	Socket head bolt M8 x 65	TSS 254-30	-	
31	Socket head bolt M8 x 60	TSS 254-31	-	
32	Hexagon thin nut M8	TSS 254-32	-	
33	Shock pad (A)	TSS 254-33	262376395	1 st
34	Hexagon socket cap screw M8 x 75	TSS 254-34	-	
35	Stand support(A)	TSS 254-35	-	
36	Knob	TSS 254-36	262376403	1 st
37	Foot	TSS 254-37	262376411	1 st
38	Stand support (D)	TSS 254-38	-	
39	Hexagon socket button head M8 x 60	TSS 254-39	-	
40	Nut M8	TSS 254-40	-	